University Of Bourgogne

Digital Signal Processing

Convolution and Correlation


Ali Mahmoud Ahmed Mohamed

January 1, 2020



Convolution:

Convolution is a mathematical way of combining two signals to form a third signal. It is the single most important technique in Digital Signal Processing. Using the strategy of impulse decomposition, systems are described by a signal called the *impulse response*. Convolution is important because it relates the three signals of interest: the input signal, the output signal, and the impulse response.



Formula of Convolution:

$$egin{align} (fst g)[n] &= \sum_{m=-\infty}^\infty f[m]g[n-m] \ &= \sum_{m=-\infty}^\infty f[n-m]g[m]. \end{split}$$

Auto Correlation:

The auto-correlation function measures the correlation of a Signal x(t) with itself shifted by some time delay j:

Its maximum value is achieved at lag =0, N, 2N (complete overlap with itself) where N is the sequence length.

The auto-correlation function can be used to detect repeats or periodicity in a signal or if it is pure random. Moreover, it can identify signals that are embedded in noise.


$$R_{yy}(\ell) = \sum_{n \in Z} y(n) \, \overline{y(n-\ell)}$$
 (Eq.7)

Cross Correlation:

In <u>signal processing</u>, cross-correlation is a <u>measure of similarity</u> of two series as a function of the displacement of one relative to the other. This is also known as a *sliding dot product* or *sliding inner-product*. It is commonly used for searching a long signal for a shorter, known feature. It has applications in <u>pattern recognition</u>, <u>single particle analysis</u>, <u>electron tomography</u>, <u>averaging</u>, <u>cryptanalysis</u>, and <u>neurophysiology</u>. The cross-correlation is similar in nature to the <u>convolution</u> of two functions. In an <u>autocorrelation</u>, which is the cross-correlation of a signal with itself, there will always be a peak at a lag of zero, and its size will be the signal energy.

$$R_{xy} = \sum_{n=0}^{N-1} x(n)y(n-k)$$

Convolution Vs. Cross-Correlation Vs. Auto-Correlation:



Convolution describes the response of a linear and time-invariant system to an input signal.

The inverse Fourier transform of the pointwise product in frequency space.

Cross-correlations a measure of similarity of two signals.

It can be used for finding a shift between two signals.

Auto-correlations
the cross-correlation of
a signal with itself.

It can be used for finding periodic signals obscured by noise.

http://en.wikipedia.org/wiki/Convolution

DSP System (Convolution & Correlation):

Add to The application the following features:

- 1. The ability to convolve two signals.
- 2. The ability to compute normalized cross-correlation of two signals or normalized auto-correlation of a signal.
- 3. The ability to compute the normalized cross-correlation of periodic signals (not necessary of same length)
- 4. Give the user the option to choose fast convolution\ correlation.

Notice:

- 1. For auto correlation only the computation of positive or negative lags is enough since it is symmetric.
- 2. The high similarity in computation between correlation and convolution



Correlation			Convelution	
Auto	✓ Direct	Periodic	Direct	signal1 o\signal\signal_1
✓ Cross	Fast	☐ Non_periodic	Fast	signal2 p\signal\signal_2
				complex
				button1
Form6				– 🗆 ×
Correlation			Convelution	aignal1 stageatteinnal 1
Auto	Direct	Periodic	☑ Direct	signal1 o\signal\signal_1. signal2 op\signal\signal_i
Cross	☐ Fast	Non_periodic	Fast	complex
				button1
				- 🗆 ×
Form6				
			Convelution	pional1 Neignal 11
Form6 Correlation Auto	Direct	Periodic	Convelution Direct	signal1 o\signal\signal_1.t